



IMO®

**Instruction Manual and Parts List
(G323FHF__ – 630M) with
Flow Serve Type Q Seal**



WARNING

This Instruction Manual and General Instructions Manual, CA-1, should be read thoroughly prior to pump installation, operation or maintenance.


Manual No. - SRM00087


Rev. 01 (21-0001)

October, 2021



READ THIS ENTIRE PAGE BEFORE PROCEEDING

FOR SAFETY OF PERSONNEL AND TO PREVENT DAMAGE TO EQUIPMENT, FOLLOWING NOMENCLATURE HAS BEEN USED IN THIS MANUAL:

	DANGER	Failure to observe precautions noted in this box can result in severe bodily injury or loss of life.
---	---------------	--

	WARNING	Failure to observe precautions noted in this box can cause injury to personnel by accidental contact with the equipment or liquids. Protection should be provided by user to prevent accidental contact.
---	----------------	--

CAUTION	ATTENTION	Failure to observe precautions noted in this box can cause damage or failure of the equipment.
----------------	------------------	--

Non compliance of safety instructions identified by following symbol could affect safety for persons: 	Safety instructions where electrical safety is involved are identified by: 	Safety instructions which shall be considered for reasons of safe operation of the pump and/or protection of pump itself are marked by sign: ATTENTION
--	---	--

ATTENTION	If operation of pump is critical to your business, we strongly recommend you keep a spare pump or major repair kit in stock at all times. As a minimum, a minor repair kit (o-rings, gaskets, shaft seal and bearings) should be kept in stock so pump refurbishment after internal inspection can be accomplished.
------------------	---

CONTENTS

Safety and Table of Contents	A
General Instructions.....	1
Introduction	1
Ordering Instructions	1
Description of the Equipment.....	1
Pump Model Identification	2
Operation	2
Parts List.....	3
Assembly and Disassembly Instructions	3-5
Troubleshooting and Field and Factory Service and Parts.....	6
Assembly Drawings	7

GENERAL INSTRUCTIONS

Instructions found herein cover disassembly, assembly and parts identification of G323FHF__-630M pumps.

NOTE: Individual contracts may have specific provisions that vary from this manual. Should any questions arise which may not be answered by these instructions, refer to General Instructions Manual, CA-1, provided with your order. For further detailed information and technical assistance please refer to Imo Pump, Technical Service Department at (704) 289-6511.

Manual cannot possibly cover every situation connected with installation, operation, inspection and maintenance of equipment supplied. Every effort was made to prepare text of manual so that engineering and design data is transformed into most easily understood wording. Imo Pump must assume personnel assigned to operate and maintain supplied equipment and apply instruction manual have sufficient technical knowledge and are experienced to apply sound safety and operational practices which may not be otherwise covered by this manual.

INTRODUCTION

Instruction manual covers Imo Pump G323FHF__-630M series pumps. Because of large number of operating conditions, it is necessary to have a variety of construction arrangements and material combinations to meet application requirements. Each pump is identified with a serial number and model designator number on pump nameplate. Definitions of model designators are given in Figure 1.

ORDERING INSTRUCTIONS

All correspondence pertaining to renewal parts for the equipment must refer to instruction manual number and should be addressed to nearest Imo representative. Handling of renewal orders will be greatly facilitated if following directions are carefully observed:

1. Give the number of the instruction manual.
2. Give the model number of the pump for which the part is desired. This number appears on the nameplate.
3. Designate the desired part by the IDP number and name as listed in Table 1 in this instruction manual.
4. Give the drawing number or figure number in which the part is shown.

For Example:


Instruction Manual No. and Revision SRM00084, Rev. 0
Model Number.....G323FHFTX-630M
Part IDP Number and Name (See Item 4 above)..... 11, Housing

DESCRIPTION OF EQUIPMENT

G323FHF__-630M series pumps are positive displacement, rotary screw type pumps. Fluid enters inlet chamber and is divided equally as it enters rotor sets. Smooth intermeshing of rotors traps and propels fluid axially in a smooth flow, without churning, pocketing or pulsating as it arrives at central discharge chamber. Two direction fluid flow keeps rotors hydraulically balanced. Fluid flowing through pump provides lubrication to wearing parts.

Instruction manual covers Imo G323FHF__-630M pumps. Model of each pump is identified on pump nameplate. Refer to figure 1 and table 1 for instructional keys when using this manual.

FIGURE 1 - PUMP MODEL IDENTIFICATION



Instruction manual covers Imo G323FHF__-630M pumps. Model of each pump is identified on pump nameplate. Refer to figure 1 and table 1 for instructional keys when using this manual.

External tubing is provided to bleed oil from both ends of pump (high pressure fluid) to pump suction. Shaft bushings are lubricated by a fluid flow between power rotor and bushing that is released back to suction through external tubing. In all cases, fluid flow through tubing ensures lubrication and cooling of bushings and mechanical seal.

Normal rotation of pump rotor is clockwise when pump is viewed from shaft end.

Note: Term outboard describes closed end of pump; term inboard describes exposed shaft end.

OPERATION

CAUTION

Operating conditions, such as speed, fluid viscosity, temperature inlet pressure, discharge pressure, filtration, duty cycle, drive type, mounting, etc. are interrelated. Due to these variable conditions, specific application limits may be different from that of operational limitations. Equipment must not be operated without verification that operating requirements are within its capabilities.

OPERATING TEMPERATURE AND THERMAL SHOCK EXPOSURE

Never operate with water. Pump is designed for liquids having general characteristics of oil. Under NO circumstances are the following operating limitations to be exceeded:

- Maximum Inlet Pressure 25 Psig
- Maximum Discharge Pressure.....300 PSIG
- Maximum Speed..... 1200 RPM
- Maximum Operating Temperature 250°F

CAUTION

Never exceed equipment's minimum or maximum allowable fluid temperature. Do not expose equipment to thermal shock. Differences in metallurgy and their respective coefficients of expansion could cause distortion of pump parts resulting in a breakdown condition.

G323FHFTX-630M Parts List

IDP	Qty	Description	Kit	IDP	Qty	Description	Kit
1	1	Case		41	2	Outboard Idlers	XX
2	2	Covers		42	1	Collar	
3	1	Rear Cover		43	1	Set Screw(s)	
5	2	Gaskets	X	44	1	Key	X
6	2	O-Rings	X	45	2	Bushings	X
9	12	Hex Cap Screws		46	1	Check Nut	
10	2	Pipe Plug		51	1	Tee	
11	2	Housings	XX	52	1	Close Nipple	
12	2	Bracket		53	2	Tubing Connectors	
13	8	Cap Screws		54	1	Tubing	
15	16	Lock Washers		55	2	Connectors	
16	8	Hex Bolts		59	40	Hex bolts	
17	2	Spring Pins		61	1	Set Screw (550J Only)	
18	1	Shim	X	62	1	Pipe Plug	
19	1	Cover	X	63	1	Seal Housing	
20	4	Capscrews	XX	64	1	Mechanical Seal	X
21	4	Lock Washers		67	1	Sleeve	
34	1	Power Rotor	XX	68	8	Hex Nut	
40	2	Inboard Idlers	XX	69	2	Set Screw	
X =	Minor Repair Kit Items						
XX =	Major Repair Kit Items (Items marked X are included in major repair kits.)						

TABLE 1 – Parts List

ASSEMBLY AND DISASSEMBLY INSTRUCTIONS

Note: Part numbers contained within parentheses such as (36) refer to balloon number as shown on assembly drawing and IDP numbers in Table 1.

WARNING

Before starting any maintenance procedure:

- Remove electrical service fuse, de-energize and lock the electrical service panel supply to the driver.
- Shut, wire or chain shut and lock all pump piping valves. If applicable, shut off any steam supply lines to the pump and/or driver.

Note: Depending on type of coupling installed (clearance between pump and driver shaft ends), maintenance to mechanical seal can be performed without removal of pump driver. If complete overhaul of pump is required, removing pump from its mounting and locating pump in a suitable work area is recommended.

If seal only is to be serviced, follow steps 1 through 4 in disassembly procedure and steps 10 through 13 in reassembly procedures.

If complete overhaul of pump is required, removal of pump from its mounting and locating the pump in a suitable work area is recommended. It is also recommended that all gaskets and seal be replaced during overhaul; regardless of their condition.

PUMP DISASSEMBLY

1. Remove tubing (54) from inboard and outboard end of pump. Tag each tube to identify installed location.
2. Loosen setscrew (61) and remove checknut (46), coupling hub and key (44).
3. Remove seal cover (63), cap screws (9), and gasket (5). Note: Mechanical seal stationary seat will be removed with seal cover (63). Remove stationary seal seat with O-ring from seal cover (63)
4. Loosen setscrews on mechanical seal (64) rotating assembly and slide assembly from shaft. Make sure setscrews are backed off enough so they will not score the shaft as assembly is removed.

If only seal replacement is to be done, disassembly is complete. Refer to assembly procedures steps 10 through 13 to reassemble seal.

If major repair is to be done proceed below.

5. Remove capscrews (9) cover (3) and gasket (5) from outboard side of pump.
6. Remove capscrews (59) from each cover (2). Remove covers (2) and o-rings (6).
7. Remove capscrews (20), washers (21), shims (18) and cover (19) from outboard bracket (12).
8. Remove both outboard and inboard brackets (12) from rotor housings (11) by removing cap screws (16) along with nuts (68) and lock washers (15) from each bracket.
9. If bushings (45) are to be replaced, remove spring pins (17) and slide bushings (45) from brackets (12).
10. Remove idlers (40,41) from rotor housings (11) by grasping inboard and outboard ends of idlers (40, 41) and pulling and rotating each idler. Slide power rotor (34) from rotor housings (11).
11. Remove both housings (11) from pump case (1) by removing cap screws and washers ((13) and (15)).
12. If thrust collar (42) is to be replaced, remove setscrew (43) from collar (42) and remove collar (42) from power rotor (34).

PUMP ASSEMBLY

Note: Clean and inspect all parts before assembly. Replace all worn or damaged parts. It is recommended that gaskets and mechanical seal be replaced regardless of their condition. Wipe each part with light lubricating oil just before installing. Rotate power rotor (34) frequently during assembly to ensure freedom of rotation.

1. Install inboard and outboard rotor housings (11) in case (1) using capscrews (13) and washers (15). Align housing (11) rotor bores such that the idler rotor bores are parallel to the pump case feet. Torque capscrews (13) to value on assembly drawing.
2. If collar (42) was removed from power rotor (34), Install collar (42) on power rotor (34) and lock in position using set screw (43). Ensure collar (42) is installed next to step cut of power rotor (34). Stake setscrew (43) to collar (42) threads using a center punch to prevent loosening.
3. If bushings (45) were removed, slide bushing (45) onto each bracket (12). Using pinhole in brackets (12) as a pilot, drill a 3/8 inch hole through bushing (45). Remove all drill burrs and install spring pin (17). DO NOT allow spring pin (17) to extend into bushing (45) bore.

4. Lubricate power rotor (34) with light oil and slide into rotor housings (11). Install inboard idler rotors (40) by aligning threads with power rotor threads, rotate idlers while pushing towards center of pump. Idler position may be observed by looking into pump inlet port. Repeat procedure for both outboard idlers (41).
5. Install assembled brackets (12) on each end of housings (11) using capscrews (16) washers (15) and nuts (68). Before tightening capscrews (16) in brackets (12), and with each bracket in place, check idlers (40, 41) to ensure bracket (12) idler stops are in line with ends of idlers. Turning power rotor (34) in its normal direction of rotation will pull idlers (40 & 41) toward center of pump. Torque capscrews (16) to value on assembly drawing.
6. Install shim (18) and cover (19) on outboard bracket (12) with capscrews (20) and washers (21). Torque capscrews (20) to value on assembly drawing.
7. Push coupling end of power rotor (34) into pump as far as it will go. Mount a dial indicator on inboard bracket (12) with indicator point resting on end of power rotor (34). Set indicator pointer to "zero". Pull power rotor (34) out from pump until collar (42) contacts face of inboard bushing (45). Check dial indicator to determine total end float travel. Correct end float is 0.055 to 0.060 inches. If end float requires shim adjustment, remove cover (19) and shim (18). Remove or add shim lamination to obtain correct end float. Brass shims have 0.003 inch lamination. Steel shims require full face grinding of metal to reduce shim thickness. Faces of steel shims after grinding are to be smooth and parallel within 0.002 inch full indicator runout (FIR). If shims are removed for adjustment, install shim (18), cover (19), capscrews (20) and washers (21). Torque capscrews (20) to value on assembly drawing. Remove dial indicator from bracket (73). Rotate power rotor (34) to check for any binding.
8. Install O-rings (6) in inboard and outboard covers (2) and install covers (2) on pump case (1) using capscrews (59). Torque capscrews (59) to value on assembly drawing.
9. Install gasket (5) and rear cover (3) on cover (2) at back end of pump using capscrews (9). Torque capscrews (9) to value on assembly drawing.
10. Installation of mechanical seal. Reference seal type in pump nomenclature and seal detail on Pump Assembly drawing. John Crane Type 8-1 and FlowServe (formerly Borg Warner) Type QWD mechanical seal rotating assembly is installed on the power rotor (34) shaft with setscrews. When the seal housing (63) is installed, with the mechanical seal stationary seat, the seal is compressed to its correct working length only if the rotating assembly is correctly positioned when it is installed.
 - a. Clean and polish pump shaft. Make sure there are no sharp edges or rough spots on shaft to damage seal O-ring (6) during installation.
 - b. Pull power rotor (34) in direction toward coupling until thrust collar (42) contacts face of bushing (45). Place a straight edge across the end face of inboard cover (2) and lightly scribe power rotor shaft at this point. Measure 15/32" from the scribe mark and lightly scribe the power rotor shaft at this point.
 - c. Apply a coat of light lubricating oil to pump shaft to aid installation of seal assembly.
 - d. Apply a coat of light lubricating oil to O-ring in seal rotating assembly and insure O-ring is properly seated in its groove. Slide seal rotating assembly on to shaft up to scribe mark that is 15/32" from end face of inboard cover (2). Securely tighten rotating assembly set screws to power rotor shaft.
 - e. Install a light coat of lubricating oil to mechanical seal stationary seat O-ring. Install mechanical seat stationary seat into seal housing (63) counter bore. Insure that slot on bottom of seal seat aligns with anti-rotation pin in seal housing counter bore.
 - f. Wipe seal faces with a clean lint free cloth.
 - g. Install seal housing, with installed seal stationary seat, to cover (2) using gasket (5) and hex capscrews (9). Torque hex capscrews (9) to value on assembly drawing.
11. Install tubing (54) from case (1) on inboard seal housing (63) and outboard cover (2) using tube fittings (55) and (53).

12. Install key (44), coupling hub and checknut (46). Lock checknut (46) in position by installing setscrew (61).
13. Install pump and align pump driver to pump following procedures for alignment in CA-1 Manual.

TROUBLESHOOTING


For assistance with troubleshooting see General Instruction Manual, CA-1

FIELD AND FACTORY SERVICE AND PARTS

Imo Pump maintains a staff of trained service personnel that can provide pump installation, pump start-up, maintenance/overhaul and troubleshooting supervision as well as installation and maintenance training.

Our factories provide maintenance as well as overhaul and test facilities the in event user prefers to return pumps for inspection or overhaul. Factory-overhauled pumps are normally tested and warranted “as-new” for a period of one year from date of shipment. For either field service or factory overhaul assistance, contact your local Imo Sales Office or representative at Technical/ Customer Service Department in Monroe, NC, USA.

Most pumps have repair kits available. Minor Repair Kits are used to repair leaking seals, bad bearings and/or for re-assembly after pump tear-down. They include (as applicable) pump shaft seals, packing, all gaskets/O-rings and bearings. Major Repair Kits are sufficient to rebuild completely worn-out pumps to “as-new” condition. They include all parts found in Minor Repair Kits plus all major internal parts subject to wear. Since kits have all necessary parts, kit purchase is preferred rather than selecting individual parts. When parts are individually selected from Parts List, some needed components are often overlooked. In addition, mixing worn or used parts with new parts risks rapid wear and shortened service life from new parts.



CIRCOR

1710 Airport Road
PO Box 5020
Monroe, NC USA
28111.5020

Tel: +1. 877.853.7867

Email: cc@circor.com

Web: www.circorpt.com

